GUIDE

Can I lift a mobility scooter into my car?

Folded weight is not the number that matters: the heaviest single piece, lifted at trunk height by the person who will actually lift it, is.

July 28, 2026 · 4 minute read



It is a fair question, and it deserves a straight answer rather than a sales pitch. The honest version is this: almost anyone can lift a mobility scooter into a car **once**. The question that actually matters is whether you can do it twice a day, in the rain, in a supermarket car park, for the next three years.

That is why this sits inside Mobility Adaptation rather than in a list of products. Getting a scooter into a car is not a single purchase. It is a decision about how you travel, made now, and revisited when your circumstances change.

What "portable" actually means

Scooters sold as portable, travel or folding scooters are designed to come apart or fold. That is genuine, and it works. But the marketing weight and the lifting weight are rarely the same number.

- **Total weight** is the whole machine, assembled, with the battery in.
- **Heaviest single piece** is the number that decides whether you can load it. On a scooter that separates, this is usually the rear section, because it carries the motor and the drive. On a folding scooter there is often no separate piece at all: you lift the entire thing in one go.
- **Battery out** reduces the load, and a removable lithium battery can make a real difference. It is also one more thing to carry, and one more thing to leave behind.

Manufacturers publish a component weight breakdown. Ask for it, in writing, before you buy anything. If a seller will not give you the heaviest single piece as a number, that tells you something.

The car matters as much as the scooter

Two things about your vehicle decide most of this, and neither is on the scooter's spec sheet:

- **Trunk lip height.** You are not lifting the scooter, you are lifting it and raising it over the lip. A high lip on an SUV can be harder than a low lip on a hatchback, even though the SUV has more space inside.
- **Trunk opening.** Not the volume, the opening. A piece that fits the trunk but not the gap through it is no use.

There is also payload. Every car has a maximum it is allowed to carry, listed on the vehicle plate and in the handbook, and that figure includes passengers, luggage and the scooter together. Check it rather than assume it.

When buying something will not fix this

Here is the part most guides leave out. If the person loading the scooter has a bad back, a shoulder problem, arthritis in the hands, or is themselves in their eighties, **no scooter is light enough**. There is no model that makes repeated awkward lifting safe. Buying a lighter machine in that situation moves the injury a few months down the road, it does not prevent it.

If that describes you, the useful options are different ones, and none of them are a lighter scooter:

- A **trunk hoist**, which lifts the scooter for you. It needs installing, wiring to the vehicle, and it uses trunk space permanently.
- A **different vehicle**, including a wheelchair accessible vehicle with a ramp, so the scooter is driven in rather than lifted.

- **Two scooters**: one kept at home, one left at a destination you visit often, such as a relative's house or a caravan.
- **Not transporting it at all.** Many shopping centers, garden centers and resorts lend scooters at the door. Some towns have a Shopmobility scheme. If your journeys are mostly to a handful of familiar places, this can be the whole answer, and it costs nothing.

A shop that hears "I cannot lift it" and offers you a lighter scooter has not listened. That is the moment to walk out.

Ramps are not the easy answer

Telescopic ramps let you load a scooter into an estate car or van without dismantling it. They work, but they need a vehicle tall enough for a sensible slope, and safe use means walking the scooter up under control rather than riding it. Short ramps into a tall trunk create a steep angle, and a steep angle is how scooters tip. If you are considering ramps, try them, loaded, before you commit.

What to measure, and what to ask

Take these to any showroom or phone call. Measure the car first, then the scooter.

- Trunk lip height from the ground, and trunk opening width and height at the narrowest point.
- Usable trunk depth with the rear seats up, since you may need the seats.
- Your car's maximum payload, from the vehicle plate.
- The scooter's **heaviest single piece**, in kilograms, in writing.
- Whether the battery is removable, and what the machine weighs without it.
- Whether the pieces have handles, or whether you are gripping a molded shell.
- Who will be loading it, on the worst day rather than the best one.
- Can you try loading that exact scooter into **your** car, before buying?

That last question is the one that settles it. Everything else is an estimate.

General information, not medical advice. If fit, posture, pressure relief or fall risk is part of your decision, speak to an occupational therapist.

SILVERA MOBILITY

silveramobility.com

Silvera selects the best wheelchairs, walkers and mobility products for different needs. No giant catalog, no confusing choices, and a plain account of what is wrong with each one.